


1 電源開關  
按 ON/OFF



2 功能設定  
選擇功能請按   
確認請按



**AUTO**

**A**

28mm

**TTL**

EV

0.0

28mm

EV Zoom

**Manual**

+1/3

1/8

3.1M 28mm

Power A.Zoom

**Av**

F2.8

18.1M 28mm

F.Stop A.Zoom

**Multi**

Frequency	10 Hz
Times	10
Power	1/128
Zoom	Auto

**Master** Ch 1

Zoom	Auto	
M	---	0.0
A	TTL	0.0
B	---	0.0
C	---	0.0

**Remote**

Channel	1
Group	A
Zoom	24 mm

**Setting** 1/2

MyTTL	0.0
Modeling	Off
Display	On
Rotate	On
ft/meter	meter

Set 等 2秒.

**TTL Advance**

Sub.Flash	Off
M.Zoom	Off

**M Advance**

Sub.Flash	Off
M.Zoom	Off
Slave	Off
ISO	200
F.Stop	F5.6

**Av Advance**

Sub.Flash	Off
M.Zoom	Off
Slave	Off
ISO	200

Set 或等 8秒.

**Setting** 2/2

Auto Off	30 min
Reset	No